

**CHAPTER - 04 HIGHLIGHTS**  
**(Summary of Changes)***Revision No. 01 Feb 24/17*

TO: HOLDERS OF THE AIRCRAFT MAINTENANCE MANUAL (06-123838)

This revision is a complete reissue of the Aircraft Maintenance Manual and all pages have been reissued.

Numerous typographical, grammar, simplified English, and/or format corrections have been made.

Changes of technical material are described below and are indicated in the text pages by revision bars in the margin adjacent to the change.

<b>CH/SE/SU Page Block No.</b>	<b>Description of Change</b>
04-00-00 PgBlk 1	Clarified Engine Fire Extinguisher Canister Limitations to: "Discard – 8 years from date of installation or 10 years from date of manufacture (whichever occurs first)"; and corrected a typo in Table 1. Structural limitations.
04-00-00 PgBlk 1	Removed life limits for PPG glass windshields.

THIS PAGE INTENTIONALLY LEFT BLANK

---

**CHAPTER 04 - AIRWORTHINESS LIMITATIONS**

## TABLE OF CONTENTS

<b>Subject</b>	<b>Chapter- Section- Subject</b>	<b>Page</b>	<b>Effectivity</b>
<b>GENERAL</b>			
Airworthiness Limitations	04-00-00	1	ALL

THIS PAGE INTENTIONALLY LEFT BLANK

## AIRWORTHINESS LIMITATIONS

AMM-04-00-00-081-801

### 1. General

SUBTASK AMM-04-00-00-081-211-001

#### A. Airworthiness limitations

##### (1) General

- (a) **The Airworthiness Limitations Section is FAA approved and specifies maintenance required under sections 43.16 and 91.403 of the Federal Aviation Regulations unless an alternative program has been FAA approved.**

##### (2) Structural Limitations

**Table 1. Structural Limitations**

Structure	Limit
<ul style="list-style-type: none"> <li>• Fuselage and associated structure</li> </ul>	<ul style="list-style-type: none"> <li>• Recurring structural inspection – every 3,300 flights</li> <li>• Life Limit – 10,000 flight hours or 10,000 flights (whichever occurs first). This life may be extended to 20,000 hours or 20,000 cycles if the aircraft is maintained in accordance with Eclipse FAA approved Service Bulletin SB 500-04-006.</li> </ul> <p><u>NOTE:</u> [1]</p>
<ul style="list-style-type: none"> <li>• Wing structure</li> </ul>	<ul style="list-style-type: none"> <li>• Recurring structural inspection – every 3,300 flights</li> <li>• Life Limit – 10,000 flight hours or 10,000 flights (whichever occurs first). This life may be extended to 20,000 hours or 20,000 cycles if the aircraft is maintained in accordance with Eclipse FAA approved Service Bulletin SB 500-04-006.</li> </ul> <p><u>NOTE:</u> [1]</p>
<ul style="list-style-type: none"> <li>• Empennage structure</li> </ul>	<ul style="list-style-type: none"> <li>• Recurring structural inspection – every 3,300 flights</li> <li>• Life Limit – 10,000 flight hours or 10,000 flights (whichever occurs first). This life may be extended to 20,000 hours or 20,000 cycles if the aircraft is maintained in accordance with Eclipse FAA approved Service Bulletin SB 500-04-006.</li> </ul> <p><u>NOTE:</u> [1]</p>



[1] Refer to [AMM-05-20-50-081-801 – Structural Inspection](#) for specific recurring structural inspection requirements and procedures.

## (3) Component Limitations

**Table 2. Component Limitations**

<b>System/Component</b>	<b>Limit</b>
<b>Chapter 24 – Electrical Power</b>	
<ul style="list-style-type: none"> <li>Aircraft System Battery PN 90-00134-001/PN F0773-3005</li> </ul>	<ul style="list-style-type: none"> <li>Capacity check – 06 month intervals</li> </ul> <p><b>NOTE:</b> Refer to <a href="#">AMM-24-32-24-071-801 – Battery - Adjustment/Test</a> for capacity check procedure.</p>
<ul style="list-style-type: none"> <li>Aircraft Start Battery PN 90-00134-001/PN F0773-3005</li> </ul>	<ul style="list-style-type: none"> <li>Capacity check – 06 month intervals</li> </ul> <p><b>NOTE:</b> Refer to <a href="#">AMM-24-32-24-071-801 – Battery - Adjustment/Test</a> for capacity check procedure.</p>
<ul style="list-style-type: none"> <li>Starter/Generator PN 200SGL149Q-( )</li> </ul>	<ul style="list-style-type: none"> <li>Overhaul – 1600 hour intervals.</li> </ul>
<b>Chapter 26 – Fire Protection</b>	
<ul style="list-style-type: none"> <li>Engine Fire Extinguisher Canister PN 26-123127-( )</li> </ul>	<ul style="list-style-type: none"> <li>Discard – 8 years from date of installation or 10 years from date of manufacture (whichever occurs first)</li> </ul>
<b>Chapter 27 – Flight Controls</b>	
<ul style="list-style-type: none"> <li>Pitch Trim Actuators PN 27-112568-( )</li> </ul>	<ul style="list-style-type: none"> <li>Return to EAI or FAA-approved facility for overhaul – 2,000 hour intervals</li> </ul>
<ul style="list-style-type: none"> <li>Rudder Force Spring Assembly PN 27-122229-( )</li> </ul>	<ul style="list-style-type: none"> <li>Discard – 10,000 flight hours</li> </ul>

System/Component	Limit
<b>Chapter 32 – Landing Gear</b>	
<ul style="list-style-type: none"> <li>Main Landing Gear (MLG) PN M041-07H101-( )</li> </ul>	<ul style="list-style-type: none"> <li>Return to EAI or FAA approved facility for overhaul – 20,000 flight hours or 20,000 landings (whichever occurs first)</li> </ul>
<ul style="list-style-type: none"> <li>Nose Landing Gear (NLG) PN M040-07H101-( )</li> </ul>	<ul style="list-style-type: none"> <li>Return to EAI or FAA approved facility for overhaul – 20,000 flight hours or 20,000 landings (whichever occurs first)</li> </ul>
<b>Chapter 35 – Oxygen</b>	
<ul style="list-style-type: none"> <li>Oxygen Cylinder PN 4441105-22C (22 cu. ft.) PN 4441105-40C (40 cu. ft.)</li> </ul>	<ul style="list-style-type: none"> <li>Hydrostatic Test – Retest 5 years from date of previous test.</li> <li>Discard – 15 years from date of manufacture</li> </ul>
<b>Chapter 56 – Windows</b>	
<ul style="list-style-type: none"> <li>Left Cockpit Side Window 56-103589-1003</li> </ul>	<ul style="list-style-type: none"> <li>Recurring inspection – 900 flights</li> </ul> <p><u>NOTE:</u> Refer to <a href="#">AMM-56-00-00-021-801 – Windows - Inspection/Check</a> for recurring inspection procedure.</p>
<ul style="list-style-type: none"> <li>Right Cockpit Side Window 56-109594-1003</li> </ul>	<ul style="list-style-type: none"> <li>Recurring inspection – 900 flights</li> </ul> <p><u>NOTE:</u> Refer to <a href="#">AMM-56-00-00-021-801 – Windows - Inspection/Check</a> for recurring inspection procedure.</p>
<b>Chapter 71 – Power Plant</b>	
<ul style="list-style-type: none"> <li>Engine Mount Isolator Bonded Assembly PN 96133–06</li> </ul>	<ul style="list-style-type: none"> <li>Discard – 3600 Hours</li> </ul>
<b>Chapter 72 – Engine – Turbine</b>	
<ul style="list-style-type: none"> <li>Life limited parts</li> </ul>	<ul style="list-style-type: none"> <li>Refer to P&amp;WC Airworthiness Limitations Manual PN 3072697</li> </ul>

FAA Approved:  DATE 2/24/17  
 Tim Smyth, Manager Propulsion Branch  
Chicago Aircraft Certification Office  
Federal Aviation Administration